

CONTROLLO REMOTO COMBINATORE TELEFONICO 2IN / 2OUT

Digitare da remoto il **CODICE** (il combinatore emette 3 beep lenti) e uno dei comandi indicati in **rosso**

STOP CHIAMATE CORRENTE digitare **CODICE + #0** (5 beep)
Il combinatore non richiama più il numero connesso fino alla conclusione del ciclo in corso.

STOP CICLO IN CORSO digitare **CODICE + #1** (5 beep)
Questo comando annulla il ciclo di chiamate correnti e comunica al combinatore di non contattare i successivi numeri della rubrica.

STOP TUTTI I CICLI digitare **SOLO CODICE MASTER + #2** (5 beep)
Interrompe il ciclo di chiamate relative a tutti i canali allarmati.

COMANDI USCITE digitare **CODICE + #3** (3 beep) + **1** oppure **2**  mess. vocale per lo stato dell'uscita selezionata + **7** oppure **9**
Consente di interrogare o comandare le uscite uscite attivazione disattivazione

INTERROGAZIONE STATO INGRESSI digitare **CODICE + #4** (3 beep) + **1** oppure **2** **7** oppure **8**  mess. vocale per lo stato dell'ingresso selezionato
Con questo comando è possibile interrogare il combinatore per conoscere lo stato dei suoi ingressi attraverso i messaggi vocali. IN1 IN2 INT1 INT2

ASCOLTO AMBIENTALE CON VIVA VOCE digitare **SOLO CODICE MASTER + #5** (3 beep) + **7**  oppure **9** 
Consente di ascoltare i rumori nell'ambiente in cui si trova il combinatore o di comunicare con eventuale utente che si trova nelle sue vicinanze. ascolto ambientale comunicazione bidirezionale con viva voce 

FUORI SERVIZIO (con STOP DI TUTTI I CICLI) digitare **SOLO CODICE MASTER + #6** (3 beep) + **SOLO CODICE MASTER** (5 beep)
Arresta ogni funzionalità del combinatore.

RIPRISTINO IN SERVIZIO digitare **SOLO CODICE MASTER + #7** (3 beep)
Riavvia ogni funzionalità del combinatore.

CHIUSURA CONNESSIONE digitare **###** (5 beep)



REMOTE CONTROL 2IN / 2OUT TELEPHONE DIALER

Remotely input the **CODE** (this command is signalled by 3 beeps) and one of the commands reported in red

STOP CURRENT CALL key in **CODE + #0** (5 beeps)

With this command, the combiner carries out no further calls to the current number.

STOP CURRENT CYCLE key in **CODE + #1** (5 beeps)

This command cancels the current call cycle and communicates to the combiner not to contact the remaining numbers in the directory.

STOP ALL CYCLES key in **MASTER CODE ONLY + #2** (5 beeps)

This command stops both the current call cycle and any waiting cycle associated with the other channel.

OUTPUT COMMANDS

Allows for control and to interrogate the outputs

key in **CODE + #3** (3 beeps) + **1** or **2**  vocal message for the status of output selected + **7** or **9**  activation  disactivation
outputs



INTERROGATION OF INPUT STATUS

With this command, it is possible to interrogate the combiner to find out the statu of inputs via voice messages.

key in **CODE + #4** (3 beeps) + **1** or **2** **7** or **8**  vocal message for the status of input selected
IN1 IN2 INT1 INT2

LOUDSPEAKER MONITORING

It allows to ear the sounds in the environment where the dialer is placed or to communicate with a user placed in its neighborhood.

key in **MASTER CODE ONLY + #5** (3 beeps) + **7**  loudspeaker monitoring or **9**  Two-way communication with viva-voce 

OUT OF ORDER (with STOP OF ALL CYCLES)

Stops all operation of the combiner.

key in **MASTER CODE ONLY + #6** (3 beeps) + **SOLO CODICE MASTER** (5 beeps)

RETURN TO SERVICE

This restarts all operation of the combiner.

key in **MASTER CODE ONLY + #7** (3 beeps)

CLOSE CONNECTION

key in **###** (5 beeps)

