

COL50FX

Colonnina 50cm per fotocellule FX40
Column 50cm for FX40 photocells
Colonne 50cm pour cellules FX40
Pilar 50cm para fotocélulas Fx40

COL100PX

Colonnina 100cm per lettore PXR o selettore a chiave SC
Column 100cm for PXR reader or key selector
Colonne 100cm pour lecteur PXR ou selecteur a clef
Pilar 100cm para lectora o selector a llave

COLPX

Tappo per colonnina COL100PX per lettore PXR
COLPX100 column cover, for PXR reader
Couverture pour colonne COLPX100 pour lecteur PXR
Tapa para columna COLPX100 para lectora PXR

COLSC

Selettore a chiave per COL100PX
Key-selector for COL100SC
Selecteur a clef pour COL100SC
Selector a llave para COL100SC

INSTALLAZIONE INSTALLATION INSTALLATION INSTALCIÓN

