



How to upgrade the FIRMWARE??



Press the "systemconfig" button



Press "select file"



Select "firmware" file then press "open"

Upgrade

File Name : C:\Documents and Settings\user\

Upload progress: _____

Upgrade **Cancel**

Press "Upgrade"

SysConfig

Network Setting
Server IP: 203 . 69 . 107 . 69
GateWay: 203 . 69 . 107 . 65
Net Mask: 255 . 255 . 255 . 248
DNS: 168 . 95 . 1 . 1
Port: 80
IP Get Method: STATIC IP

Mail Setting
Mail Server: 0.0.0.0
UserName: _____
Password: _____
Mail From: _____
Mail to: **Add Mail List**

IO Port Setting
Port 1: **CAM** DeviceID: 0
Port 2: **CAM** DeviceID: 0
 Enable ALARM DURATION 10 SEC

Password Setting
New Password: *****
Confirm: *****
ACCOUNT MANAGEMENT

Firmware Upgrade
Upgrade Firmware: **Select File**

System Utility
Maxim Online User Number: 10
Bandwidth of Server: 512 K

Apply **Cancel** **REBOOT**

Press "Cancel" to finish the upgrade